





WB-1030 INVENTORY LIST

<u>TUXEDO CODE</u>	<u>DESCRIPTION</u>	<u>M. REF</u>	
WB-1030-7000	Cabin, Wheel Balancer	101	
WB-1030-7001	Cover, Frame	102	
WB-1030-7002	Screw, Frame Cover, M5 X 12	103	
WB-1030-7003	Belt	104	
WB-1030-7004	Flat Washer #8 (Motor Mount)	105	
WB-1030-7005	Washer, Elastic #8 (Motor Mount)	106	
WB-1030-7006	Screw, M8 X 25 (Motor Mount)	107	
WB-1030-7007	Pulley	108	
WB-1030-7008	Pin, Retaining	109	
WB-1030-7009	Motor	110	
WB-1030-7010	Cable	111	
WB-1030-7011	Transformer	112	
WB-1030-7012	Spacer, Nylon	113	
WB-1030-7013	Circuit Board	114	
WB-1030-7014	Paper, Insulated	115	
WB-1030-7015	Resistor	116	
WB-1030-7016	Clip	117	
WB-1030-7017	Screw, M4 X 10	118	
WB-1030-7018	Washer, Elastic #4	119	
WB-1030-7019	Flat Washer #4	120	
WB-1030-7020	Handle, Wheel Balancer	121	
WB-1030-7021	Cone, # 1	122	
WB-1030-7022	Cone, # 2	123	
WB-1030-7023	Cone, # 3	124	
WB-1030-7024	Gauge, Width	125	
WB-1030-7025	Screw, M6 X 16	126	
WB-1030-7026	Scale Handle	127	
WB-1030-7027	Rod, Scale	128	
WB-1030-7028	Guide, Scale	129	
WB-1030-7029	Circlip, #25	130	
WB-1030-7030	Support, Scale	131	
WB-1030-7031	Screw, M5 X 12	132	
WB-1030-7032	Guide, Scale End	133	
WB-1030-7033	Spring	134	
WB-1030-7034	Flat Washer #6	135	
WB-1030-7035	Hammer, Balance Weight	136	
WB-1030-7036	Cover, W/Weight Tray	137	
WB-1030-7037	Screw, M5 X 12	138	
WB-1030-7038	Panel	139	
WB-1030-7039	Computer Board	140	
WB-1030-7040	Spring	141	
WB-1030-7041	Tube for Hood	142	
WB-1030-7042	Support	143	
WB-1030-7043	Microswitch	144	
WB-1030-7044	Flat Washer #4	145	
WB-1030-7045	Washer, Elastic #4	146	
WB-1030-7046	Screw, M4 X 30	147	
WB-1030-7047	Flat Washer #10	148	
WB-1030-7048	Washer, Elastic #10	149	

WB-1030 INVENTORY LIST

<u>TUXEDO CODE</u>	<u>DESCRIPTION</u>	<u>M. REF</u>	
WB-1030-7049	Screw, M10 X 20	150	
WB-1030-7050	Lock Ring, Frame	151	
WB-1030-7051	Nut, M6	152	
WB-1030-7052	Screw, M6 X 40	153	
WB-1030-7053	Screw, M6 X 16	154	
WB-1030-7054	Locknut, M10	155	
WB-1030-7055	Frame, Tube	156	
WB-1030-7056	Screw, M10 X 50	157	
WB-1030-HD-1	Hood	158	
WB-1030-7058	Screw, M5.5 X 25	159	
WB-1030-7059	Switch, Main	160	
WB-1030-7060	Screw, M10 X 160	201	
WB-1030-7061	Terminal, Threaded Rod	202	
WB-1030-7062	Flange	203	
WB-1030-7063	Shaft, Main	204	
WB-1030-7064	Flat Washer #8	205	
WB-1030-7065	Screw, M8 X 25	206	
WB-1030-7066	Pulley	207	
WB-1030-7067	Screw, M5 X 10	208	
WB-1030-7068	Cover, Bearing	209	
WB-1030-7069	Screw, M5 X 16	210	
WB-1030-7070	Bracket	211	
WB-1030-7071	Washer, Elastic #4	212	
WB-1030-7072	Flat Washer, #4	213	
WB-1030-7073	Screw, M4 X 8	214	
WB-1030-7074	Disk, Phase	215	
WB-1030-7075	Circlip, #25	216	
WB-1030-7076	Bearing, 6005Z	217	
WB-1030-7077	Bearing, 6006Z	219	
WB-1030-7078	Spindle	220	
WB-1030-7079	Flat Washer, #10	231	
WB-1030-7080	Washer, Elastic #10	232	
WB-1030-7081	Screw, M10 X 20	233	
WB-1030-7083	Encoder Board	228	
WB-1030-7084	Adjusting Plate	226	
WB-1030-7085	Rod, Eye	234	
WB-1030-7086	Nut, M10	235	
WB-1030-7087	Washer	236	
WB-1030-7088	Sensor, Piezo	237	
WB-1030-7089	Cable of Sensor	238	
WB-1030-7090	Nut, M10	239	
WB-1030-7091	Rod, Thread	240	
WB-1030-7092	Screw, 2.2 X 15, Self Tapping	241	
WB-1030-7093	Cover	242	
WB-1030-7094	Spring	243	
WB-1030-7095	Plate	244	
WB-1030-7096	Cover, Plastic	245	
WB-1030-7097	Nut	246	
WB-1030-7098	Pin, 5 Dia X 35	247	

